


VOLA HV1, HV3, HV4

Fitting instruction
 Montageanleitung
 Monteringsvejledning
 Monteringsvægledning
 Montage hanleiding
 Manuel de montage




HV1, HV3:
 04/00020
 04/00028



| HV1, HV3 | L | H | h |
|-----------|------------------|-------------------|------------------|
| Std.: | 114 mm 4 1/2" | 120 mm 4 3/4" | 27 mm 1" |
| +30: | 114 mm 4 1/2" | 150 mm 6" | 56 mm 2 1/4" |
| /150: | 150 mm 6" | 120 mm 4 3/4" | 27 mm 1" |
| +30/150: | 150 mm 6" | 150 mm 6" | 56 mm 2 1/4" |
| +170: | 114 mm 4 1/2" | 290 mm 11 1/2" | 197 mm 7 3/4" |
| +170/150: | 150 mm 6" | 290 mm 11 1/2" | 197 mm 7 3/4" |





HV1:






Data, 3 Bar:

| Max. | l/min. | Gal/min. |
|--------|--------|----------|
| HV1/3: | 5,0 | 1,3 |
| HV4 | 9,0 | 2,0 |

Max. 70°C, 158°F








HV1: Ø10
 HV1JP: Ø10
 HV1US: Ø3/8"
 HV1Q: Ø3/8"

HV1US:



- | | |
|------------|--|
| VR277K: | VR22, VR269, VR277 |
| *VR17L4K: | VR15P, VR16L4, VR17L (US-Standard) |
| *VR17L5K: | VR15P, VR16L5, VR17L (Standard) |
| *VR17L9K: | VR15P, VR16L9, VR17L (Japan Standard) |
| *VR17LSK: | VR15P, VR16LS, VR17L |
| VR297/L/M: | VR20, VR22, VR269, VR273/L/M, VR277, VR294, VR295, VR296 |
| VR433: | VR261, VR263, VR440, VR442, 2xVR444 |
| NR.10/L/M: | VR20, VR22, VR273/L/M, VR294, VR295 |



vola
 Lunavej 2
 DK-8700 Horsens
 Tlf : + 45 7023 5500
 sales@vola.com
 www.vola.com

VOLA HV1

Date
 Okt. 16

Rev.
 6

Sheet
 SB 21.1